

TECHNICAL DOCUMENTATION

FEATURES

- External 230V 50/60Hz power supply.
- Up to 3 speeds control for ceiling fans.
- Manual control through push button and LED indicator.
- 10 Logic functions.
- Total data saving on KNX bus failure.
- Integrated KNX BCU.
- Dimensions 67 x 90 x 35mm (2 DIN units).
- DIN rail mounting (EN 50022), through pressure.
- Conformity with the CE directives (CE-mark on the right side).




Figure 1: FANinBOX 230V 1CH

Power supply input	2. Fan output	3. Speed control buttons	Speed indicator LEDs
Programming/Test button	6. Progra	ımming/Test LED	7. KNX Connector

Programming/test button: short press to set programming mode. If this button is held while plugging the device into the KNX bus, it enters the safe mode. If this button is held for more than 3 seconds, the device enters the test mode.

Programming/Test LED: programming mode indicator (red). When the device enters the safe mode, it blinks (red) every half second. The manual mode is indicated by the green color. During the start-up (reset or after KNX bus failure) and if the device is not in safe mode, it starts a blue blinking sequence.


CONCEPT		DESCRIPTION				
Type of devic	е		Electric operation control device	ce		
Voltage (typical)		al)	29VDC SELV			
KNX supply	Voltage range		2131VDC	2131VDC		
	Maximum	Voltage	mA	mW		
	consumption	29VDC (typical)	3.9	113.1		
	Consumption	24VDC ¹	10	240		
	Connection type			Typical TP1 bus connector for 0.80mm Ø rigid cable		
External power	er supply			230VAC 50/60Hz		
Operation ten	nperature			0°C +55°C		
Storage temp	erature		-20°C +55°C	-20°C +55°C		
Operation hu			5 95% (No condens.)			
Storage humidity		5 95% (No condens.)	5 95% (No condens.)			
Complementary characteristics		Class B	Class B			
Protection class		II				
Operation type		Continuous operation	Continuous operation			
Device action type		Type 1	Type 1			
Electrical stress period		Long				
Degree of protection		IP20, clean environment				
Installation		Independent device to be mou 50022)	Independent device to be mounted inside electrical panels with DIN rail (EN 50022)			
Minimum clearances		Not required	Not required			
Response on KNX bus failure		Data saving according to parameterization				
Response on KNX bus restart		Data recovery according to parameterization				
Operation indicator		(green). The output LEDs ind	The programming LED indicates programming mode (red) and test mode (green). The output LEDs indicate its status (fixed = full speed; fast/slow flashing = high/slow speed; off = stoped)			
Weight		109g				
PCB CTI index		175V				
Housing material		PC FR V0 halogen free	PC FR V0 halogen free			


¹ Maximum consumption in the worst case scenario (KNX Fan-In model)


OUTPUTS SPECIFICATIONS AND CONNECTIONS				
CONCEPT		DESCRIPTION		
Number of outputs		1		
Output type		Relays based control device		
Maximum recommended load per output		100W		
Minimum load per output		30W		
Short-circuit protection		NO		
Overload protection		NO		
Connection method		Screw terminal block		
Cable cross-section		0.5-2,5mm ² (IEC) / 26-12AWG (UL)		
Outputs per common		1		
Maximum response time		15ms		
Lifetime (cycles)	Mechanical (min.)	1 000 000 (@ 180cpm)		
	Electrical (min.)	50 000 (@20cpm, max. current and resistive load)		

EXTERNAL POWER SUPPLY SPECIFICATIONS AND CONNECTIONS		
CONCEPT	DESCRIPTION	
Voltage	230VAC	
Connection method	Screw terminal block	
Cable cross-section	0.5-2,5mm ² (IEC) / 26-12AWG (UL)	

WIRING DIAGRAMS









 \triangle In order to ensure the expected status of the relays, please check that the device is connected to the KNX bus before energizing the power circuit.


⚠ Use for ceiling fans. Do not use other load to avoid damages.

Figure 2: Wiring diagram of a fan


Attaching FANinBOX 230V 1CH to DIN rail:









Removing FANinBOX 230V 1CH from DIN rail:










Figure 3: Mounting FANinBOX 230V 1CH on DIN rail



SAFETY INSTRUCTIONS

- Installation should only be performed by qualified professionals according to the laws and regulations applicable in each country.
- Do not connect the mains voltage nor any other external voltage to any point of the KNX bus; it would represent a risk for the entire KNX system. The facility must have enough insulation between the mains (or auxiliary) voltage and the KNX bus or the wires of other accessories, in case of being installed.
- The facility must be equipped with a device that ensures the omnipolar sectioning. Installation of a 10A mini-circuit-breaker is recommended. To prevent accidents, it must remain open in case of manipulation of the device.
- Once the device is installed (in the panel or box), it must not be accessible from outside.
- Keep the device away from water and do not cover it with clothes, paper or any other material while in use.
- The WEEE logo means that this device contains electronic parts and it must be properly disposed of by following the instructions at http://zennio.com/weee-regulation.